

Marshall

MONITOR II A.N.C.

USER MANUAL

LEGAL AND TRADEMARK NOTICE

- Design of device and packaging are intellectual properties of Zound Industries International AB. © All Rights Reserved. Zound Industries International AB is hereinafter referred to as "Zound Industries".
- MARSHALL, Marshall Amps, their respective logos, "Marshall" and "Marshall" trade dress are trademarks and intellectual property of Marshall Amplification Plc and may not be used without permission. Permission granted to Zound Industries.
- The Bluetooth® wordmark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Zound Industries is under license.
- Google Play and the Google Play logo are trademarks of Google LLC.
- Apple and the Apple logo are trademarks of Apple Inc. registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- All other trademarks are the property of their respective owners and may not be used without permission.

For more legal information related to this product and to its use in your specific region, and for more detailed information about Zound Industries and partner & license information, please visit the website: www.marshallheadphones.com. The user is recommended to visit the website regularly for up-to-date information.

Zound Industries International AB, Centralplan 15, 111 20 Stockholm, Sweden

DISCLAIMER

Use of the Made for Apple badge means that an accessory has been designed to connect specifically to the Apple product(s) identified in the badge and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

The availability of third party services may need separate agreements between you and any third party and Zound Industries International AB do not take responsibility for the availability of such services.


Stated play time is calculated using a random selection of music, played at medium volume.

The information contained herein is correct at the time of publication, with reservation for editorial errors. This product is software dependent and its functions and compatibility can change when updating the software.

Designed in Stockholm • Produced in China

INDEX

- 002. LEGAL AND TRADEMARK NOTICE**
- 006. GETTING STARTED**
- 006. DEVICE LAYOUT**
- 007. THE CONTROL KNOB**
- 008. THE LED INDICATOR**
- 008. CHARGING YOUR HEADPHONES**
- 009. THE ANC MODE BUTTON**
- 010. THE M-BUTTON**
- 010. THE 3.5 MM INPUT**
- 011. TROUBLESHOOTING**



GETTING STARTED

001. Push and hold the control knob until the LED indicator blinks blue.
002. Select **MONITOR II** from your audio device's Bluetooth® list.
003. Download the Marshall Bluetooth app and follow the in-app instructions to setup the M-button, adjust ANC, customise the EQ settings and more.

Get the **Marshall Bluetooth** app on Google Play or the App Store.

It is recommended to charge the battery before using your headphones for the first time.

DEVICE LAYOUT

001. Customisable M-button
002. ANC mode button
003. LED indicator
004. 3.5 mm input
005. USB-C port for charging
006. Multi-directional control knob

THE CONTROL KNOB

Use the control knob on the right ear cap to control audio, start Bluetooth® pairing mode and turn the headphones on or off.

FUNCTION	ACTION
POWER ON/OFF	Push and hold for 2 seconds
PLAY/PAUSE	Single-click
SKIP FORWARD	Push to the right
SKIP BACK	Push to the left
FAST FORWARD	Push to the right and hold
REWIND	Push to the left and hold
TURN UP THE VOLUME	Push upwards
TURN DOWN THE VOLUME	Push downwards
HANDLE CALLS	Single-click to answer or end call
	Double-click to reject an incoming call

THE LED INDICATOR

The LED indicator is located on the left ear cap and shows the headphones status:

LED STATUS	HEADPHONES STATUS
RED-ORANGE-YELLOW-GREEN	Charging (0-100% battery level)
WHITE LIGHT BLINKING EVERY 5TH SECOND	Powered on, connected to a Bluetooth® device with audio paused
WHITE BLINKING	Searching for previously paired devices
BLUE BLINKING	Bluetooth pairing mode
OFF	Power off or playing via Bluetooth

CHARGING YOUR HEADPHONES

When the battery charge is low, an alert will sound.

Plug your headphones into a USB power source via the USB-C cable to charge the battery. A full battery recharge takes approximately 2 hours, and 15 minutes of charging can get you up to 5 hours of wireless playtime.

THE ANC MODE BUTTON

Monitor II A.N.C. utilise Active Noise Cancelling (ANC) technology that continuously pinpoints and measures ambient noise to control how much of the outside world you hear.

There are two ANC modes.

- **Active noise cancelling** - Block out the noise and focus on what is playing.
- **Monitoring mode** - Let the outside world in to engage in a conversation or listen to an announcement.

Use the ANC button to quickly change between modes.

001. Short press toggles **Active noise cancelling** and **Monitoring mode**

002. Push and hold for 2 seconds to turn ANC off or on

The level of noise cancelling and monitoring can be adjusted in the **Marshall Bluetooth** app.

THE M-BUTTON

The M-button can be set to switch between three different equaliser presets or alternatively, your phones voice assistant or the Google Assistant.

Go to the Marshall Bluetooth app and configure the M-button from the M-Button settings menu

Note: Voice assistant may not be available in your country and requires a separate account/agreement between you and the third party service.

THE 3.5 MM INPUT

To use the Monitor II A.N.C. with a wired device, simply use the 3.5 mm cable included. Once connected, Bluetooth will disconnect for audio streaming. You can still use ANC, as long as your headphones are turned on.

When the 3.5 mm cable is disconnected, the headphones will try to reconnect with the last connected Bluetooth device.

TROUBLESHOOTING

PROBLEM	CAUSE	ACTION
CANNOT PAIR WITH A BLUETOOTH DEVICE	The headphones are not in pairing mode.	Make sure the headphones are turned off. Push the control knob for 4 seconds, until the LED indicator blinks blue. Select MONITOR II from your Bluetooth device list.
	Your headphones are connected to the 3.5 mm lead.	Disconnect the 3.5 mm cable from your headphones before Bluetooth pairing
ANC IS NOT WORKING	Your headphones are not turned on.	Push the control knob for 2 seconds to turn on your headphones.
	ANC is not on.	Push the ANC button for 2 seconds to turn ANC on. Short-press the ANC button to toggle the ANC modes.
	ANC level is turned down in the Marshall Bluetooth app.	Go to the Marshall Bluetooth app and set the level of the ANC in the ANC settings menu.

PROBLEM	CAUSE	ACTION
THERE ARE TWO INSTANCES OF MONITOR II IN THE BLUETOOTH DEVICE LIST	Monitor II A.N.C. uses two Bluetooth connections. One connection is for audio streaming and the other is a low energy Bluetooth connection for the app.	This is normal behaviour and no action is needed.
THE HEADPHONES ARE NOT RESPONDING	A software error has occurred.	Perform a hardware reset: Push and hold the M-button while pushing the control button downwards. If the problem persists, perform a factory reset. Note: This will delete all user settings and after the factory reset, the headphones need to be set up again. Push and hold both the M-button and the control knob for 7 seconds until the LED indicator turns purple.

MARSHALLHEADPHONES.COM

Marshall

MONITOR II A.N.C.

РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ

LEGAL AND TRADEMARK NOTICE

- Design of device and packaging are intellectual properties of Zound Industries International AB. © All Rights Reserved. Zound Industries International AB is hereinafter referred to as "Zound Industries".
- MARSHALL, Marshall Amps, their respective logos, "Marshall" and "Marshall" trade dress are trademarks and intellectual property of Marshall Amplification Plc and may not be used without permission. Permission granted to Zound Industries.
- The Bluetooth® wordmark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by Zound Industries is under license.
- Google Play and the Google Play logo are trademarks of Google LLC.
- Apple and the Apple logo are trademarks of Apple Inc. registered in the U.S. and other countries. App Store is a service mark of Apple Inc., registered in the U.S. and other countries.
- All other trademarks are the property of their respective owners and may not be used without permission.

For more legal information related to this product and to its use in your specific region, and for more detailed information about Zound Industries and partner & license information, please visit the website: www.marshallheadphones.com. The user is recommended to visit the website regularly for up-to-date information.

Zound Industries International AB, Centralplan 15, 111 20 Stockholm, Sweden

ОТКАЗ ОТ ОТВЕТСТВЕННОСТИ

Использование знака «Сделано для Apple» означает, что этот аксессуар разработан специально для продукта или продуктов Apple, указанных на знаке, а разработчик подтвердил, что он соответствует стандартам эффективности Apple. Apple не несет ответственности за функционирование этого устройства или его соответствие стандартам безопасности или регулятивным нормам.

Доступность сервисов сторонних поставщиков может потребовать дополнительных соглашений между вами и третьей стороной, и Zound Industries International AB не несет ответственности за доступность указанных сервисов.

Оставшееся время воспроизведения рассчитывается по случайно выбранной композиции, воспроизводимой при средней громкости.

Содержащаяся здесь информация является верной на момент публикации с поправкой на редакторские ошибки. Работа этого изделия зависит от программного обеспечения, и его функции и параметры совместимости могут измениться при изменении или обновлении программного обеспечения.

Разработано в Стокгольме • Изготовлено в Китае

СОДЕРЖАНИЕ

002. LEGAL AND TRADEMARK NOTICE

006. ПЕРЕД ИСПОЛЬЗОВАНИЕМ

006. ПАНЕЛЬ УПРАВЛЕНИЯ УСТРОЙСТВА

007. КНОПКА УПРАВЛЕНИЯ

008. СВЕТОДИОДНЫЙ ИНДИКАТОР


008. ЗАРЯДКА НАУШНИКОВ

009. КНОПКА ВЫБОРА РЕЖИМА ANC

010. M-КНОПКА

010. ВХОД 3,5 ММ

011. ПОИСК И УСТРАНЕНИЕ НЕИСПРАВНОСТЕЙ



ПЕРЕД ИСПОЛЬЗОВАНИЕМ

001. Нажмите и удерживайте кнопку управления до тех пор, пока светодиодный индикатор не начнет мигать синим цветом.
002. Выберите в списке Bluetooth® своего устройства **MONITOR II**.
003. Скачайте приложение Marshall Bluetooth и следуйте инструкциям в нем для настройки М-кнопки, ANC, эквалайзера и т. д.

Скачайте приложение **Marshall Bluetooth** в Google Play или App Store.

Перед первым использованием наушников рекомендуется зарядить батарею.

ПАНЕЛЬ УПРАВЛЕНИЯ УСТРОЙСТВА

001. Индивидуально настраиваемая М-кнопка
002. Кнопка выбора режима ANC
003. Индикатор состояния
004. Вход 3,5 мм
005. Разъем USB-C для зарядки
006. Многонаправленная кнопка управления

КНОПКА УПРАВЛЕНИЯ

Кнопка управления на правом наушнике предназначена для управления звуком, включения режима сопряжения Bluetooth® и включения/выключения наушников.

ФУНКЦИЯ	ДЕЙСТВИЕ
ВКЛЮЧЕНИЕ/ВЫКЛЮЧЕНИЕ	Нажмите и удерживайте в течение 2 секунд
ВОСПРОИЗВЕДЕНИЕ/ПАУЗА	Нажмите однократно
ПЕРЕМОТАТЬ ВПЕРЕД	Нажмите вправо
ПЕРЕМОТАТЬ НАЗАД	Нажмите влево
ПЕРЕМОТАТЬ ВПЕРЕД	Нажмите вправо и держите
ПЕРЕМОТАТЬ НАЗАД	Нажмите влево и держите
УВЕЛИЧИТЬ ГРОМКОСТЬ	Нажмите вверх
СНИЗИТЬ ГРОМКОСТЬ	Нажмите вниз
ОТВЕТЫ НА ЗВОНКИ	Нажмите однократно, чтобы ответить на звонок или завершить звонок Нажмите дважды, чтобы отклонить входящий звонок

СВЕТОДИОДНЫЙ ИНДИКАТОР

Светодиодный индикатор состояния находится на левом наушнике

СТАТУС СВЕТОДИОДНОГО ИНДИКАТОРА	СТАТУС НАУШНИКОВ
КРАСНЫЙ-ОРАНЖЕВЫЙ-ЖЕЛТЫЙ-ЗЕЛЕНый	Зарядка (уровень батареи 0-100%)
БЕЛый, МИГАЕТ КАЖДую ПЯТую СЕКУНДУ	Включены, подключены к устройству с Bluetooth, воспроизведение находится на паузе
МИГАЕТ БЕЛым ЦВЕТом	Поиск ранее сопряженных устройств
МИГАЕТ СИНИМ ЦВЕТом	Режим сопряжения Bluetooth
НЕ ГОРИТ	Отключен или воспроизводит по Bluetooth

ЗАРЯДКА НАУШНИКОВ

О низком заряде батареи извещает звуковой сигнал.

Для зарядки батареи подключите наушники к источнику питания USB кабелем USB-C. Для полной зарядки батареи требуется приблизительно 2 часа, а 15 минут зарядки позволяют прослушивать музыку в беспроводном режиме до 5 часов.

КНОПКА ВЫБОРА РЕЖИМА ANC

В модель Monitor II A.N.C. используется технология активного шумоподавления (Active Noise Cancelling, ANC), при которой окружающие звуки определяются, а их уровень измеряется так, чтобы можно было контролировать, в каком объеме вы их слышите.

Существует два режима ANC.

- **Активное шумоподавление:** шум блокируется, подчеркивается воспроизводимый материал.
- **Режим мониторинга:** окружающие звуки слышны так, чтобы участвовать в разговоре или прослушать объявление.

Для быстрого переключения между режимами нажимайте кнопку ANC.

001. При коротком нажатии происходит переключение между режимами **активное шумоподавления** и **мониторинга**
002. Нажмите и удерживайте кнопку в течение 2 секунд для включения и выключения ANC

Уровень шумоподавления и мониторинга можно регулировать в приложении **Marshall Bluetooth**.

М-КНОПКА

М-кнопка может настраиваться так, чтобы переключаться между тремя настройками эквалайзера или, в качестве альтернативы, голосовым ассистентом или Google Assistant.

Для настройки М-кнопки откройте меню М-кнопки в приложении Marshall Bluetooth.

Примечание. Голосовой ассистент может быть недоступен в вашей стране, и может потребоваться отдельная учетная запись/отдельное соглашение между вами и сторонней службой.

ВХОД 3,5 ММ

Для использования Monitor II A.N.C. с проводным устройством достаточно подключить комплектный кабель 3,5 мм. После подключения передача звука по Bluetooth будет отключена. ANC можно использовать, пока наушники включены.

После отключения кабеля 3,5 мм наушники попытаются повторно подключиться к последнему сопряженному устройству Bluetooth.

ПОИСК И УСТРАНЕНИЕ НЕИСПРАВНОСТЕЙ

ПРОБЛЕМА	ПРИЧИНА	ДЕЙСТВИЕ
НЕВОЗМОЖНО ВЫПОЛНИТЬ СОПРЯЖЕНИЕ С УСТРОЙСТВОМ BLUETOOTH	Наушники не находятся в режиме сопряжения.	Убедитесь, что наушники отключены. Нажмите и удерживайте кнопку управления 4 секунды до тех пор, пока светодиодный индикатор не замигает синим цветом. Выберите MONITOR II II из списка устройств Bluetooth.
	Наушники подключены кабелем 3,5 мм.	Отключите кабель 3,5 мм от наушников перед сопряжением по Bluetooth
ANC НЕ РАБОТАЕТ	Наушники не включены.	Нажмите и удерживайте кнопку управления в течение 2 секунд для включения наушников.
	ANC не включена.	Нажмите кнопку ANC и удерживайте ее 2 секунды для включения ANC. Коротким нажатием кнопки ANC переключайте режимы ANC.
	Установлен низкий уровень ANC в приложении Marshall Bluetooth.	Перейдите в приложение Marshall Bluetooth и установите уровень ANC в настройках ANC.

ПРОБЛЕМА	ПРИЧИНА	ДЕЙСТВИЕ
В СПИСКЕ BLUETOOTH-УСТРОЙСТВ НАХОДЯТСЯ ДВА УСТРОЙСТВ MONITOR II	Monitor II A.N.C. использует для Bluetooth-подключения. Одно предназначено для потоковой передачи звука, а другое — для энергосберегающего Bluetooth-подключения приложения.	Это нормальное поведение, действий не требуется.
НАУШНИКИ НЕ РЕАГИРУЮТ	Возникла программная ошибка.	Выполните аппаратный сброс. Нажмите и удерживайте M-кнопку одновременно с нажатием нижней части управляющей кнопки. Если проблема не исчезнет, выполните сброс к заводским настройкам. Примечание. В этом случае все пользовательские настройки будут удалены и наушники придется настраивать снова. Нажмите и удерживайте M-кнопку одновременно с управляющей кнопкой и удерживайте их в течение 7 секунд до тех пор, пока светодиодный индикатор не станет пурпурным.

MARSHALLHEADPHONES.COM